




ASSEMBLING INSTRUCTIONS FOR THE SLATWALL SYSTEMS

Art. 231
Slats 8x124 cm


1



The panel must jut out for 4 cm both at the beginning and at the end.


1• Fasten the upright to the wall using the screws and anchors (Art. 232).

2




2• Fasten the panels to the vertical strips using the screws (Art. 233) while maintaining the slats raised from the floor by 2.5 cm.

3






• Articles 212-214-215 must always start and end at 1.6 cm from the edge of the panels.


3• When lower panel assembling is completed, nail the joint (Art. 215) using a nail every 50 cm. ~





4• Overturn the panels and screw them to the upper part of the wall.



ASSEMBLING INSTRUCTIONS FOR THE SLATWALL SYSTEMS



5* When the lower panels have been put in place, insert the horizontal profiles by using a rubber mallet or a hammer with a buffer.



6* To insert end pieces, make a light pressure with your hands.

The maximum loading capacity of the shelves used on slatwall systems max 20 kg. To increase these values, add more screws to lock the bed cover. Screws must be 3x25mm

Application example for Art. 213



L'art. 214 may also be used as Terminal instead of Art. 213 in this case, it is necessary to leave 1.0cm instead of 1.6cm from the edge of the Panel.